Power Management Options POWER MANAGEMENT SERIAL PORTS ENABLED HARD DISK TIMEOUT 1 Minute DISPLAY TIMEOUT 28 Minutes STANDBY MODE TIMEOUT Never Timeout RESUME MODE OFF SUSPEND TIMEOUT Never Timeout ESC TO QUIT, USE UP/DOWN ARROWS TO MOVE F1 TO UPDATE USE LEFT/RIGHT ARROWSTO CHANGE

Using the POWER383 Utility:

The power program (Power383) lets you temporarily change the powermanagement parameters without restarting the computer. These parameters let you do the following:

- * Turn power management on or off
- * Turn the floppy disk controller and Resume on or off
- * Enable or disable the serial ports
- * Set the hard drive, standby mode, and suspend mode timeouts

To run the power program, follow these steps:

- 1. Exit any program you are running.
- 2. If you are not in Drive C, type the following: c:<ENTER>
- 3. Select the DOS directory by typing the following: cd \dos <ENTER>
- 4. At the prompt, type the following: power383 <ENTER>

Note: Refer to (Keyboard) Faxback Doc. # 1234 for more information on Power Management using the Functions Key Combinations.

(jej-05/11/94)